








# FORD COURIER - 2WD

PC, PD, PE, PG, PH 1985 to 11/2006

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle
SHOCK ABSORBERS				
	35mm Gas Bulged Shock Absorbers - Piranha		SA35649GP	2 ea
TORSION BARS				
	Increased Rate Torsion Bars Length 898mm		MAZDA009	1 pr
SHOCK MOUNT REINFORCEMENT BRACKET				
	Shock Absorber Top Mount Reinforcement Bracket		SHOCKBRKT-MAZ1	1 ea
SHOCK ABSORBERS				
	35mm Gas Bulged Shock Absorbers - Piranha		SA35636GP	2 ea
	35mm <b>Adjustable</b> Shock Absorbers - Piranha		SA35636GPA	
LEAF SPRINGS				
	Raised Height Heavy Duty 6 + 2 Leaf Springs LBA up to 250kg		MAZDA006	2 ea
	Raised Height Extra Heavy Duty 7 + 2 Leaf Springs LBA 300kg to 500kg		MAZDA006M	
SHACKLE BUSH KITS				
	Polyurethane Bush Kit		BU756UK	1 kit
U-BOLTS				
	Round Form U Bolts - With Nuts * Check U bolt dimensions before ordering as some later models vary		UB451	4 ea
SHACKLES				
	Greaseable Shackles		S386-1K	2 ea
PINS				
	Greaseable Pins		P794	2 ea

F  
R  
O  
N  
T

R  
E  
A  
R

\* LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)  
NOTE: 4 x 2 Hi-Rider models 2004 to 2006 are exceptions.  
Refer 4 x 4 section of catalogue