

FORD FALCON Wagon - 2WD

XE-XF 6 Cyl & V8, EA-EL 6 Cyl, EB-EL V8, AU 6 Cyl & V8, BA-BF, BF MK II & III

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle		
SHOCK ABSORBERS						
	Gas Shocks - XE to XF		SAB28160	2 ea	F R O N T	
	Gas Struts - EA to EL		SAB28240			
	Gas Struts - AU I, II, III		SAB28800			
	Gas Struts BA to BF		SAB36690			
COIL SPRINGS						
	Standard Height Plus Heavy Duty Coil Springs	20mm	H/Duty Coil available on request for each model	1 pr		
SHOCK ABSORBERS						
	Gas Shock Absorbers - XE to EL		SAB28220	2 ea	R E A R	
	Gas Shock Absorbers - AU to BF		SAB36670			
LEAF SPRINGS						
	Raised Height Heavy Duty 6 Leaf Springs Fixed end eye = 54mm Must use BlueMax bush kit with these springs LBA up to 400kg	15-20mm	FORD020	2 ea		
SHACKLE BUSH KITS						
	Polyurethane Bush Kit		BU744UK	1 kit		
U-BOLTS						
	Early Models up to BA			4 ea		
	Round Form U Bolts - With Nuts					
	UB258 = 230mm x 75mm x 7/16" round		UB258			
	UB258L = 260mm x 75mm x 7/16" round		UB258L			
	After BA					
	Round Form U Bolts - With Nuts		UB458			
	UB458 = 190mm x 75mm x 9/16" round					
SANDWICH PLATES						
	U Bolt Sandwich Plates - sold in pairs		SPS-FORD	2 pr		

* LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)