AU, BA-BF, FG Ute	N Utility - 2WD  Not Suitable for RTV Utilities				
Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
SHOCK ABSORBERS					
	AU, AU11-A11 V6 & V8, XR6 & XR8 Ute		SAB28800		
	BA to BF - ALL Utes		SAB36690	 2 ea	
( <del>-</del>	FG-XR6 & XR8 & XR6 Turbo & R6 Ute		SA673637G		
COIL SPRINGS  WWW MAN	Standard Height Plus Heavy Duty Coil Springs	40mm	H/Duty Coil available on request for each model	1 pr	
SHOCK ABSORBERS	AU-BF - 07/1999 to 09/2006		SAB36660	2 ea	
	FG-XR6 & XR8 & XR6 Turbo Ute - 02/2008 Onwards		SAS314317 SAS314316	1 R 1 L	
	FG-R6 Ute - 02/2008 Onwards		SAS314315	2 ea	
LEAF SPRINGS	NB: Not Suitable For XR6/XR8 Models Raised Height Heavy Duty 4 + 2 Leaf Springs LBA up to 400kg	25-30mm	FORD021	2 ea	
	Raised Height Extra Heavy Duty 5 + 2 Leaf Springs  LBA 500kg to GVM	25-30mm	FORD021M		
SHACKLE BUSH KITS	Polyurethane Bush Kit  Fixed end eye = 54mm  Must use BlueMax bush kit with these springs		BU744UK	1 kit	
J-BOLTS	Daving Farms II Dalta - With Nints				
	Round Form U Bolts - With Nuts  UB458 = 190mm x 75mm x 9/16" round		UB458		
	UB458-1 = 210mm x 75mm x 9/16" round		UB458-1	_	
	<b>OR</b> UB453-1 = 215mm x 83mm x 9/16" round		UB453-1	4 ea	
SANDWICH PLATES	U Bolt Sandwich Plates - <b>sold in pairs</b> FORD021 2pr FORD021M 4pr		SPS-FORD	2/4pr	

<sup>\*</sup> LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)