TOYOTA HI- 300 Series 4/201	9 Onwards  Description	Approx	Part	Qty Per	
SHOCK ABSORBERS	Description	Lift	Number	Vehicle	
OHOOK ABOOKBERG	30mm Gas Shock Absorbers		ТВА	2 ea	F R
COIL SPRINGS	Raised Height Heavy Duty Coil Springs		ТВА	1 pr	O N T
SHOCK ABSORBERS	35mm <b>Adjustable</b> Shock Absorbers - Piranha		SA35650GPA	2 ea	
LEAF CODINGS	oommin negaciacia onesiin nama				
LEAF SPRINGS	OE Replacement 3 Leaf Parabolic Springs	20mm	TOY030P		
0	Heavy Duty 4 Leaf Parabolic Springs LBA 300kg to 500kg	20mm	TOY030MP		R E
SHACKLE BUSH KITS					Α
	Polyurethane Bush Kit - Until a Polyurethane Kit can be developed. Reuse bushes out of factory springs		ТВА	1 kit	R
U-BOLTS	Square Form U Bolts - With Nuts				
	use with TOY030P		UB480	— 4 ea	
I Ball	Square Form U Bolts - With Nuts use with TOY030MP		UB481	, ca	

<sup>\*</sup> LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)