

FORD MAVERICK - 4WD

Y60 Cab Chassis & Utility 1988 to 1994

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle
SHOCK ABSORBERS				
	35mm Gas Bulged Shock Absorbers		SA35661G	2 ea
	41mm Foam Cell Shock Absorbers		SA41661FC	
STEERING DAMPER				
	Steering Damper - Pre 9/1989	Eye/Eye	SD14034G	1 only
	Expanded Body Steering Damper - 9/1989 Onwards	Pin/Pin	SD35036	
LEAF SPRINGS				
	Raised Height Heavy Duty 7 Leaf Springs Heavy duty	50mm	NISS011	2 ea
SHACKLE BUSH KITS				
	Polyurethane Bush Kit		BU718UK	1 kit
U-BOLTS				
	Square Form U Bolts - With Nuts		UB436	3 N/S
	Square Forged U Bolts - With Nuts		UB669F	1 D/S
SHACKLES				
	Greaseable Shackles Anti-Inversion Shackles Also Available		S353K	2 ea
PINS				
	Greaseable Pins		P667	2 ea
SHOCK ABSORBERS				
	35mm Gas Bulged Shock Absorbers - Piranha		SA35648GP	2 ea
	41mm Foam Cell Shock Absorbers Urethane boot optional extra		SA41648FC	
LEAF SPRINGS				
	Raised Height Heavy Duty 7 + 2 Leaf Springs LBA up to 300kg	50mm	NISS012D-S NISS012N-S	1 D/S 1 N/S
	Raised Height Extra Heavy Duty 9 + 2 Leaf Springs LBA 400kg to 600kg	50mm	NISS012MH	
	Raised Height Extra Heavy Duty 7 + 2 Leaf Springs with 10mm main & wrap leaves - constant load LBA 600kg to GVM	50mm	NISS012GV	2 ea
SHACKLE BUSH KITS				
	Polyurethane Bush Kit		BU719UK	1 kit
U-BOLTS				
	Round Form U Bolts - With Nuts		UB453	4 ea
SHACKLES				
	Greaseable Shackles Anti-Inversion Shackles Also Available		S353K	2 ea
PINS				
	Greaseable Pins		P667	2 ea

F
R
O
N
T

R
E
A
R

* **LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)**