FORD F250 -	4WD				
2000 Onwards					
Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
SHOCK ABSORBERS					
O piranha	35mm Gas Bulged Shock Absorbers - Piranha		SA35101GP	2 ea	
LEAF SPRINGS					
	Raised Height Heavy Duty Parabolic Springs 3 Leaf - LBA up to 100kg	50mm to 75mm	FORD033P3	2 ea	
SHACKLE BUSHES					_
1111 00	Silent Block Bush - Front Spring Eye		BU150	2 ea	F R
11.44	Silent Block Bush - Rear Spring Eye		BU149	2 ea	0
3336	Polyurethane Bush Kit - Does Not Include Chassis/Shackle Bushes.		TBA	1 kit	N T
PINS					-
	Greaseable Pins - Front Eye Only Greaseable Pins - Rear Eye Only. Will not fit Shackle		P1136 P1134	2 ea 2 ea	
U-BOLTS	State of the state			_ 0	
	Square Form U Bolts - With Nuts		UB471	4 ea	
PANHARD RODS					
•	Adjustable Panhard Rod		PRF250	1 ea	
SHOCK ABSORBERS	Overal Overage in a				
O piranha	Quad Suspension 35mm Gas Bulged Shock Absorbers - Piranha		SA35102GP	4 ea	
LEAF SPRINGS					
	Raised Height Heavy Duty 4 + 2 Leaf Springs LBA up to 500kg	50mm	FORD031	— 2 ea	
	Raised Height Heavy Duty 5 + 2 Leaf Springs LBA 500kg to 800kg	50mm	FORD031M		
SHACKLE BUSHES				_	
2222 22	Silent Block Bush - Front Spring Eye		BU150	2 ea	
	Silent Block Bush - Rear Spring Eye		BU149	2 ea	
8866	Polyurethane Bush Kit - Does Not Include Chassis/Shackle Bushes.		ТВА	1 kit	R E
PINS					A
	Greaseable Pins - Front Eye Only Greaseable Pins - Rear Eye Only. Will not fit Shackle		P1136 P1134	2 ea 2 ea	R
U-BOLTS	Croadoughe i into Roan Lyo Giny. Will not int Ghadale			2 00	
	Round Form U Bolts - With Nuts		UB472	_ ,	
	Round Form U Bolts - With Nuts use with FORD031M		UB472-1	4 ea	
POLYAIR SPRINGS					
	Polyair Bellows Kit F250, F350 2000 onwards 4 shock rear	RSD	PA85301	1 kit	
	Spacer Bracket use with RSD suspension		SP-F250	- 4 ea	
	Square Form U Bolts - With Nuts to suit spacer bracket		UB381	- 4 ea	

^{*} LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)