

FORD F350 - 4WD

2000 Onwards

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle
SHOCK ABSORBERS				
	35mm Gas Bulged Shock Absorbers - Piranha		SA35101GP	2 ea
LEAF SPRINGS				
	Raised Height Heavy Duty Parabolic Springs 3 Leaf - LBA up to 100kg	50mm to 75mm	FORD033P3	2 ea
SHACKLE BUSHES				
	Silent Block Bush - Front Spring Eye		BU150	2 ea
	Silent Block Bush - Rear Spring Eye		BU149	2 ea
	Polyurethane Bush Kit - Does Not Include Chassis/Shackle Bushes.		TBA	1 kit
PINS				
	Greaseable Pins - Front Eye Only		P1136	2 ea
	Greaseable Pins - Rear Eye Only. Will not fit Shackle		P1134	2 ea
U-BOLTS				
	Square Form U Bolts - With Nuts		UB471	4 ea
PANHARD RODS				
	Adjustable Panhard Rod		PRF250	1 ea
SHOCK ABSORBERS				
	35mm Shock Absorbers		SA35102GP	2 ea
LEAF SPRINGS				
	Raised Height Heavy Duty Leaf Springs *** Made to Order ***	50mm	FORD038	2 ea
SHACKLE BUSHES				
	Silent Block Bush - Front Spring Eye		BU150	2 ea
	Silent Block Bush - Rear Spring Eye		BU149	2 ea
	Polyurethane Bush Kit - Does Not Include Chassis/Shackle Bushes.		TBA	1 kit
PINS				
	Greaseable Pins - Front Eye Only		P1136	2 ea
	Greaseable Pins - Rear Eye Only. Will not fit Shackle		P1134	2 ea
U-BOLTS				
	Round Form U Bolts - With Nuts ** Confirm Measurements		TBA	4 ea

F
R
O
N
T

R
E
A
R

* **LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)**