Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle
HOCK ABSORBERS				
piranha	35mm Gas Bulged Shock Absorbers - Piranha		SA35091GP	— 2 ea
	41mm Foam Cell Shock Absorbers		SA41091FCN	2 Ca
EERING DAMPER				
(check end type)	Steering Damper - Pre 9/1989	Eye/Eye	SD14034G	— 1 only
	Expanded Body Steering Damper - 9/1989 Onwards	Pin/Pin	SD35036	
OIL SPRINGS  WWW MANAGEMENT OF THE PRINCE OF	Raised Height Heavy Duty Coil Springs No LBA	50mm	NIS-200	— 1 pr
	Raised Height Heavy Duty Coil Springs With LBA to 45kg - steel bar and/or winch	50mm	NIS-201	
ASTER BUSH KIT	Correct castor angles by using Castor Bush Kit BU1721UK (2 degrees) for 50mm lift		BU1721UK	
OCK ABSORBERS				
piranha	35mm Gas Bulged Shock Absorbers - Piranha		SA35094GP	— 2 ea
	41mm Foam Cell Shock Absorbers		SA41094FC	
OIL SPRINGS	Raised Height Heavy Duty Coil Springs  LBA 100kg to GVM	50mm	NIS-213	— 1 pr
	Raised Height Heavy Duty Coil Springs  LBA 150kg to GVM	50mm	NIS-214	

<sup>\*</sup> LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)