Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle
SHOCK ABSORBERS				
o piranha	35mm Gas Bulged Shock Absorbers - Piranha		SA35091GP	— 2 ea
	41mm Foam Cell Shock Absorbers		SA41091FCN	2 00
STEERING DAMPER				
	Expanded Body Steering Damper	Pin/Pin	SD35036	1 only
COIL SPRINGS				
	Standard Height Heavy Duty Coil Springs	STD +	NIS-204	
	Raised Height Heavy Duty Coil Springs LBA up to 45kg	50mm	NIS-201	1 pr
	Raised Height Heavy Duty Coil Springs LBA 50kg to 80kg	50mm	NIS-201HD	
CASTER BUSH KIT				
	Correct castor angles by using Castor Bush Kit BU1721UK (2 degrees) for 50mm lift		BU1721UK	1 kit
SHOCK ABSORBERS				
oiranha A	35mm Gas Bulged Shock Absorbers - Piranha		SA35094GP	— 2 еа
o pranta	41mm Foam Cell Shock Absorbers		SA41094FC	
COIL SPRINGS				
	Standard Height Heavy Duty Coil Springs	STD	NIS-210LP	<u></u>
	Raised Height Heavy Duty Coil Springs LBA up to 150kg	50mm	NIS-214	
	Raised Height Heavy Duty Coil Springs Progressive Rate LBA 200kg to 400kg - constant load	50mm	NIS-209HD	1 pr
	Raised Height Heavy Duty Coil Springs Progressive Rate Constant 500kg to GVM	50mm	NIS-211SP	

^{*} LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)