NISSAN PAT		de			
GU / Y61 Cab Ch Part and Location	assis & Utility Coil Springs 5/1999 Onw Description	Approx Lift	Part Number	Qty Per Vehicle	
SHOCK ABSORBERS			Tumbo.	70010	
O piranha 0	35mm Gas Bulged Shock Absorbers - Piranha		SA35091GP	— 2 ea	
	41mm Foam Cell Shock Absorbers		SA41091FCN	— 2 ea	
STEERING DAMPER					
	Steering Damper **WSL**	Pin-Pin	SD14011	1 only	F
	Expanded Body Steering Damper - Piranha		SD35011GP		
COIL SPRINGS					R
	Standard Height Heavy Duty Coil Springs	STD +	NIS-204	_	N T
	Raised Height Heavy Duty Coil Springs LBA up to 45kg	50mm	NIS-201	1 pr	
	Raised Height Heavy Duty Coil Springs LBA 50kg to 80kg	50mm	NIS-201HD		
CASTER BUSH KIT					
	Correct castor angles by using Castor Bush Kit BU1721UK (2 degrees) for 50mm lift		BU1721UK	1 kit	
SHOCK ABSORBERS					
O pirantha o	35mm Gas Bulged Shock Absorbers - Piranha		SA35094GP	— 2 ea	
	41mm Foam Cell Shock Absorbers		SA41094FC		
COIL SPRINGS					
	Raised Height Heavy Duty Coil Springs LBA up to 100kg	50mm	NIS-214		R E A R
	Raised Height Heavy Duty Coil Springs LBA up to 250kg - Progressive Rate	50mm	NIS-209HD		
	Raised Height Heavy Duty Coil Springs LBA 200kg to 350kg - constant load	50mm	NIS-214HD	1 pr	
	Raised Height Heavy Duty Coil Springs 450kg to GVM - constant load when fitting NIS-214EHD it is recommended to fit coil tower brace bracket	50mm	NIS-214EHD	-	

^{*} LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)