

TOYOTA LANDCRUISER - 4WD

FJ60 / HJ60 Station Wagon 1980 to 1990

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle		
SHOCK ABSORBERS						
	35mm Gas Bulged Shock Absorbers - Piranha		SA35637GP	2 ea	F R O N T	
STEERING DAMPER (right angle pin)						
	Expanded Body Steering Damper - Piranha		SD35024GP	1 only		
LEAF SPRINGS						
	Raised Height Heavy Duty 7 Leaf Springs Comfort - no load	50mm	TOY006	2 ea	F R O N T	
SHACKLE BUSH KITS						
	Polyurethane Bush Kit		BU719UK	1 kit		
U-BOLTS						
	Square Form U Bolts - With Nuts		UB436	4 ea	F R O N T	
SHACKLES						
	Heavy Duty Greaseable Shackles		S353K	2 ea		
	Anti - Inversion Shackle L/H optional	Must fit in pairs	S353KLH	1 L/H		
	Anti - Inversion Shackle R/H optional		S353KRH	1 R/H	F R O N T	
PINS						
	Greaseable Pins		P351	2 ea		
SHOCK ABSORBERS						
	Pre 10/1985 35mm Gas Bulged Shock Absorbers - Piranha		SA35636GP	2 ea	R E A R	
	Post 10/1985 35mm Gas Bulged Shock Absorbers - Piranha		SA35650GP			
	41mm Foam Cell Shock Absorbers		SA41094FC			
LEAF SPRINGS						
	Raised Height Heavy Duty 6 + 1 Leaf Springs	50mm	TOY007CN/S TOY007CD/S	1 only	R E A R	
SHACKLE BUSH KITS						
	Polyurethane Bush Kit		BU719UK	1 kit		
U-BOLTS						
	Round Form - With Nuts		UB453-3	4 ea	R E A R	
SHACKLES						
	Heavy Duty Greaseable Shackles		S353K	2 ea		
	Anti - Inversion Shackle L/H optional	Must fit in pairs	S353KLH	1 L/H		
	Anti - Inversion Shackle R/H optional		S353KRH	1 R/H	R E A R	
PINS						
	Greaseable Pins		P351	2 ea		

* **LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)**