FORD MAVEF Y60 SWB Hardtop	RICK - 4WD 1988 to 1994				
Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
SHOCK ABSORBERS					
piranha 0	35mm Gas Bulged Shock Absorbers - Piranha		SA35091GP		
	41mm Foam Cell Shock Absorbers		SA41091FCN		
STEERING DAMPER					
	Steering Damper - Pre 9/1989	Eye/Eye	SD14034G	1 only	F
	Expanded Body Steering Damper - 9/1989 Onwards	Pin/Pin	SD35036		R
COIL SPRINGS					0
	Raised Height Heavy Duty Coil Springs No bar / winch	50mm	NIS-200	— 1 pr	N T
	Raised Height Heavy Duty Coil Springs With bar / winch	50mm	NIS-201	īβī	
CASTER BUSH KIT					
	Correct castor angles by using Castor Bush Kit BU1721UK (2 degrees) for 50mm lift		BU1721UK	1 kit	
SHOCK ABSORBERS					
• piranha	35mm Gas Bulged Shock Absorbers - Piranha		SA35094GP		
	41mm Foam Cell Shock Absorbers		SA41094FC		R
COIL SPRINGS					Ε
WYYW	Raised Height Heavy Duty Coil Springs LBA up to 100KG	50mm	NIS-213	4	A R
ELLAND	Raised Height Heavy Duty Coil Springs LBA 200kg to GVM	50mm	NIS-214	— 1 pr	

^{*} LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)