







VW AMAROK - 4WD

2010 Onwards *Excludes V6 Models

Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle		
STRUT						
	Strut/Gas Spring Seat Shock Absorbers - Piranha		SA67090GP	2 ea	F R O N T	
COIL SPRINGS						
	Raised Height Heavy Duty Coil Springs No bar / Winch	20mm	VW-201	1 pr		
	Raised Extra Height Heavy Duty Coil Springs With bar / Winch	20mm	VW-201H			
SHOCK ABSORBERS						
	35mm Gas Bulged Shock Absorbers - Piranha		SA35085GP	2 ea	R E A R	
LEAF SPRINGS						
	Raised Height Heavy Duty Leaf Springs 3 + 3 LBA 200 kg to 400kg	20mm	VW001M	2 ea		
	Raised Height Extra Heavy Duty Leaf Springs 3 + 3 LBA 500kg to GVM - Additional camber	20mm	VW001MH			
SHACKLE BUSH KITS						
	Polyurethane Bush Kit * does not include chassis bushes		BU780UK	1 kit		
U-BOLTS						
	Round Form U Bolts - With Nuts		UB453-3	4 ea		

* LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)