FORD F350 -	4WD				
2000 Onwards					
Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
SHOCK ABSORBERS			Trainisci.	10111010	
o piranha	35mm Gas Bulged Shock Absorbers - Piranha		SA35101GP	2 ea	
LEAF SPRINGS					
	Raised Height Heavy Duty Parabolic Springs  3 Leaf - LBA up to 100kg - bushes supplied pre fitted	50mm to 75mm	FORD033P3	0	
	Raised Height Extra Heavy Duty Parabolic Springs 4 leaf - use with extreme loads LBA 100kg plus - bushes supplied pre fitted	50mm to 75mm	FORD033P4	— 2 ea	
SHACKLE BUSHES	Silent Block Bush Shockle Bin Upper 9 Louer		BU149	4.00	F
1111 00	Silent Block Bush - Shackle Pin Upper & Lower Silent Block Bush - Fixed Pin		BU150	4 ea — 2 ea	R
11111			50100		O N
3336	Also available as Polyurethane Bush Kit		BU740UK	1 kit	Т
PINS				•	
1 mm	Greaseable Pins - Front Eye Only Greaseable Pins - Rear Eye Only. Will not fit Shackle		P1136 P1134	2 ea 2 ea	-
U-BOLTS					
	Square Form U Bolts - With Nuts		UB471	4 ea	
PANHARD RODS	Adjustable Panhard Rod		PRF250	1 ea	
SHOCK ABSORBERS	35mm Shock Absorbers		SA35102GP	2 ea	
LEAF SPRINGS					
	Raised Height Heavy Duty Leaf Springs *** Made to order ***	50mm	FORD038	2 ea	
SHACKLE BUSHES					R
2222 00	Silent Block Bush - Shackle Pin Upper & Lower		BU149	4 ea	E
	Silent Block Bush - Fixed Pin		BU150	2 ea	A R
	Also available as Polyurethane Bush Kit		BU740UK	1 kit	
PINS	Greaseable Pins - <b>Front Eye Only</b>		P1136	2 ea	
4	Greaseable Pins - Rear Eye Only. Will not fit Shackle		P1134	2 ea	
U-BOLTS	Round Form U Bolts - With Nuts		ТВА	4 ea	

<sup>\*</sup> LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)