NISSAN PATI GQ / Y60 SWB Sta		8 to 1998			
Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
SHOCK ABSORBERS					
piranha 0	35mm Gas Bulged Shock Absorbers - Piranha		SA35091GP	— 2 ea	
	41mm Foam Cell Shock Absorbers		SA41091FCN	— 2 c a	F R O N T
STEERING DAMPER (check end type)	Steering Damper - Pre 9/1989	Eye/Eye	SD14034G	— 1 only	
	Expanded Body Steering Damper - 9/1989 Onwards	Pin/Pin	SD35036	— I Offig	
COIL SPRINGS	Raised Height Heavy Duty Coil Springs No LBA	50mm	NIS-200	— 1 pr	
	Raised Height Heavy Duty Coil Springs With LBA to 45kg - steel bar and/or winch	50mm	NIS-201		
CASTER BUSH KIT	Correct castor angles by using Castor Bush Kit BU1721UK (2 degrees) for 50mm lift		BU1721UK	1 kit	
SHOCK ABSORBERS					
• piranha	35mm Gas Bulged Shock Absorbers - Piranha		SA35094GP	— 2 ea	R E A R
	41mm Foam Cell Shock Absorbers		SA41094FC		
COIL SPRINGS	Raised Height Heavy Duty Coil Springs LBA 100kg to GVM	50mm	NIS-213	— 1 pr	
	Raised Height Heavy Duty Coil Springs LBA 150kg to GVM	50mm	NIS-214	ı pı	

^{*} LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)