Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle
SHOCK ABSORBERS				
o piranba	35mm Gas Bulged Shock Absorbers - Piranha		SA35091GP	— 2 ea
- Jacobson	41mm Foam Cell Shock Absorbers		SA41091FCN	
STEERING DAMPER				
	Steering Damper **WSL**	Pin-Pin	SD14011	— 1 only
## S	Expanded Body Steering Damper - Piranha		SD35011GP	
COIL SPRINGS				
	Standard Height Heavy Duty Coil Springs	STD +	NIS-204	1 pr
	Raised Height Heavy Duty Coil Springs  LBA up to 45kg	50mm	NIS-201	
	Raised Height Heavy Duty Coil Springs  LBA 50kg to 80kg	50mm	NIS-201HD	
CASTER BUSH KIT				
	Correct castor angles by using Castor Bush Kit BU1721UK (2 degrees) for 50mm lift		BU1721UK	1 kit
SHOCK ABSORBERS				
o piranha o	35mm Gas Bulged Shock Absorbers - Piranha		SA35094GP	— 2 ea
	41mm Foam Cell Shock Absorbers		SA41094FC	2 Ca
COIL SPRINGS	B :			
	Raised Height Heavy Duty Coil Springs  LBA up to 100kg	50mm	NIS-214	
CON NOO	Raised Height Heavy Duty Coil Springs  LBA up to 250kg - Progressive Rate	50mm	NIS-209HD	_
WWW IO	Raised Height Heavy Duty Coil Springs  LBA 200kg to 350kg - constant load	50mm	NIS-214HD	1 pr
	Raised Height Heavy Duty Coil Springs 450kg to GVM - constant load when fitting NIS-214EHD it is recommended to fit coil tower brace bracket	50mm	NIS-214EHD	_

<sup>\*</sup> LBA = Load Bearing Accessories (Bull Bar, Winch, Tyre Carrier, Extra Fuel Tanks etc)