TOYOTA LANDCRUISER - 4WD					
VDJ76 Station Wag	on 2007 Onwardss				
Part and Location	Description	Approx Lift	Part Number	Qty Per Vehicle	
SHOCK ABSORBERS					
	35mm Gas Bulged Shock Absorbers - Piranha		SA35097GP		
O piranha O	35mm <b>Adjustable</b> Shock Absorbers - Piranha 41mm Foam Cell Shock Absorbers		SA35097GPA SA41091FCT	2 ea	
STEERING DAMPER	4 min i dan dei dilock Absolbers		0A410311 01		
ļ d	Expanded Body Steering Damper - Piranha		SD35047GP	1 only	
COIL SPRINGS					
	Standard Height Heavy Duty Coil Springs	STD +	TLC-207		
	Raised Height Heavy Duty Coil Springs  No Bar / Winch	50mm	TLC-203		F
<b>WWWW</b>	Raised Extra Height Heavy Duty Coil Springs Progressive Rate - With Bar / Winch	50mm	TLC-203HT	1 pr	R O
	Raised Height Extra Heavy Duty Coil Springs	50mm	TLC-203HD		N
CASTER BUSH KIT	Extreme loads to GVM				Т
35 III	Correct castor angles by using Castor Bush Kit BU1721UK (2 degrees) for 50mm lift		BU1721UK	1 kit	
ABS EXTENSION					
T. Carl	ABS Extension - Does not suit later models with DPF		ACCABSXT- TOY01	1 kit	
SWAY BAR SPACERS					
Great States	Sway Bar Spacer		ACCSWBB- TOY02	2 ea	
SHOCK ABSORBERS					
	35mm Gas Bulged Shock Absorbers - Piranha		SA35099GP		
O piranha	35mm <b>Adjustable</b> Shock Absorbers - Piranha		SA35099GPA	 2 ea	
	41mm Foam Cell Shock Absorbers		SA41094FC		
LEAF SPRINGS					
	Raised Height Medium Duty 5 + 2 Leaf Springs <b>LBA up to 200kg</b>	50mm	TOY050M		
	Raised Height Heavy Duty 8 + 2 Leaf Springs	50mm	TOVOSOMU	2 ea	
	LBA 250kg to 400kg	50mm	TOY050MH		
SHACKLE BUSH KITS					
	Polyurethane Bush Kit - Suits SSA Shackles & Pins Shackle Widths May Vary Between Brands		BU779UK	1 kit	R E
U-BOLTS (check length re					A
o Bozio (oncok lengario	oquii ou)				R
	Round Form U Bolts - With Nuts		UB453-3	— 4 ea	
0114 01/1 50	Round Form U Bolts - With Nuts		UB416	1 00	-
SHACKLES	Greaseable Shackles		S358HDK	2 ea	
PINS					
	Greaseable Pins		P356HD	2 ea	
BRAKE PROPORTION SP					
a.	Brake Proportioning Spacer		SP-TOY-BRK01	1 ea	